


Eighth St West First Floor

Emergency Evacuation
Assembly Point is the
Woodruff Parking Lot to West

For emergency access contact the duty staff pager at
404-533-7197 or the campus police at 404-894-2500




Eighth St West 2nd Floor

Emergency Evacuation
Assembly Point is the
Woodruff Parking Lot to West



Use Stairs.
Do not use elevators

For emergency access contact the duty staff pager at
404-533-7197 or the campus police at 404-894-2500




Eighth St West 3rd Floor

Emergency Evacuation
Assembly Point is the
Woodruff Parking Lot to West

Use Stairs.
Do not use elevators

For emergency access contact the duty staff pager at
404-533-7197 or the campus police at 404-894-2500



Eighth St West 4th Floor

Emergency Evacuation
Assembly Point is the
Woodruff Parking Lot to West



Use Stairs.
Do not use elevators

For emergency access contact the duty staff pager at
404-533-7197 or the campus police at 404-894-2500